

HEAT-STERILIZABLE, REMOTELY ACTIVATED  
BATTERY DEVELOPMENT PROGRAM  
PHASE II  
Fourth Quarterly Report


Period: April 1, 1969 to June 30, 1969

Contract No. 952214

NAS7-100

July 25, 1969

JET PROPULSION LABORATORY  
California Institute of Technology  
4800 Oak Grove Drive  
Pasadena, California 91103



ELECTRONICS DIVISION  
Eagle-Picher Industries, Inc.  
Couples Department  
Joplin, Missouri

FACILITY FORM 602	N60-38661	
	(ACCESSION NUMBER)	(THRU)
	98	1
	(PAGES)	(CODE)
CR-106112		03
(NASA CR OR TMX OR AD NUMBER)		(CATEGORY)

Reproduced by the  
**CLEARINGHOUSE**  
for Federal Scientific & Technical  
Information Springfield Va. 22151

HEAT-STERILIZABLE, REMOTELY ACTIVATED

BATTERY DEVELOPMENT PROGRAM

PHASE II

Fourth Quarterly Report

Period: April 1, 1969, to June 30, 1969

Contract No. 952214

NAS7-100

July 25, 1969

"This work was performed for the Jet Propulsion Laboratory,  
California Institute of Technology, as sponsored by the  
National Aeronautics and Space Administration under Contract  
NAS7-100."

ELECTRONICS DIVISION  
Eagle-Picher Industries, Inc.  
Couples Department  
Joplin, Missouri

"This report contains information prepared by Eagle-Picher Industries, Inc., under JPL Sub-Contract. Its content is not necessarily endorsed by The Jet Propulsion Laboratory, California Institute of Technology, or The National Aeronautics and Space Administration."

### ABSTRACT

This report discusses the progress during the fourth quarter of the development of a heat-sterilizable, sealed, remotely activated battery per contract number 952214 between The Jet Propulsion Laboratory and Eagle-Picher Industries, Inc. The work is moving to the completion of Phase I and initiation of Phase II. Phase I is defined as an investigation of basic cell and battery components. Phase II consists of the assembly of the components selected from Phase I into a battery.

Studies pertaining to the silver-oxide electrode have shown that prior to sterilization the crystalline structure is irregular and has no similarity between plates. After sterilization the plates become more uniform on a plate-to-plate comparison but are less uniform across the surface of an individual plate. X-Ray analysis revealed that prior to sterilization the only phase present was AgO. The predominant phases found after sterilization were Ag and Ag<sub>2</sub>O with a small amount of AgCO<sub>3</sub>.

The zinc electrode was found to be physically stable through heat sterilization. This was verified through microscope scanning shots, X-Ray measurements and B.E.T. surface area measurements.

Due to heat sterilization the resistivity of the separator is reduced to a level slightly above that which would be expected after 24 hours immersion in 1.30 specific gravity potassium hydroxide.

Mechanical tests conducted with molded polysulfone cell cases indicate a 40% loss in strength due to 135°C heat sterilization.



## TABLE OF CONTENTS

<u>SECTION</u>		<u>PAGE</u>
ABSTRACT		iii
List of Tables		v
List of Figures		vi
1.0	INTRODUCTION	1
2.0	TECHNICAL DISCUSSION	1
	2.1 Silver-Oxide Electrode	1
	2.2 Zinc Electrode	5
	2.3 Separator	6
	2.4 Cell Case and Sealing	6
	2.5 Pyrotechnics	12
	2.6 Cell Design	12
3.0	CONCLUSIONS	13
4.0	RECOMMENDATIONS	20
5.0	NEW TECHNOLOGY	20
APPENDIX I	Microscopic Study of Silver-Oxide Electrodes	21
APPENDIX II	Microscopic Study of Zinc Electrodes	51

# LIST OF TABLES

<u>TABLE</u>		<u>PAGE</u>
Table I	Effects of Sterilization on Silver-Oxide and Zinc Electrodes	2
Table II	Effects of 135°C Sterilization on the Surface Area of Zinc Plates	7
Table III	Effects of Heat Sterilization on the Resistance of Separator Material	9
Table IV	Mechanical Strengths of Sterilized and Unsterilized Polysulfone Joints	11

## LIST OF FIGURES

<u>FIGURE</u>		<u>PAGE</u>
Figure I	Fixture for Separator Resistance Measurement	8
Figure II	Cell No. 1 Discharge Characteristics	14
Figure III	Cell No. 2 Discharge Characteristics	15
Figure IV	Cell No. 3 Discharge Characteristics	16
Figure V	Cell No. 4 Discharge Characteristics	17
Figure VI	Cell No. 6 Discharge Characteristics	18
Figure VII	Cell No. 7 Discharge Characteristics	19

## 1.0 INTRODUCTION

This report presents the results of work during the fourth quarter ending 30 June 1969. The individual components necessary for a remotely activated heat-sterilized battery were studied. Also, some preliminary design and testing of cells were accomplished.

## 2.0 TECHNICAL DISCUSSION

### 2.1 Silver-Oxide Electrode

During the past quarter studies were made to determine the effects of heat sterilization on various physical parameters of the silver-oxide electrode. These included crystalline structure, porosity, and chemical compounds. The methods used were microscope scanning, X-Ray diffraction, and B.E.T. measurements. Additional measurements were made of the weight losses and increases in thickness. These are shown in Table I.

The work pertaining to the crystalline structure and phase changes was performed by the University of Missouri at Rolla. The B.E.T. tests were performed by American Instruments Company. Analysis was made on plates before and after sterilization.

Microscopic examination was made of nine electrodes representing four weight groups. Each was compressed to a different density as is indicated by the thickness variations shown in Table I. The views included transverse as well as flat surface shots of the plates. Magnifications of 300X and 1000X were used. The pictures are shown in Appendix I. Evaluation of the scanning microscope shots was made without knowing the thickness so as not to influence the conclusions.

The transverse shots revealed irregularities or variations in density through the thickness of the electrodes. This was due to the pressing operation and pressure variations through the thickness caused by both depth and the presence of the silver grid. In general, however, the electrode structure was fairly uniform.

TABLE I  
EFFECTS OF STERILIZATION  
ON  
SILVER-OXIDE AND ZINC  
ELECTRODES

Plate No.	Type	Weight		% Change	Thickness		% Change
		Before	After		Before	After	
35	Silver	6.604	6.314	-4.3	.026	.029	+11.5
106	"	6.698	6.387	-4.6	.028	.035	+25.0
83	"	6.594	6.286	-4.7	.028	.033	+17.9
95	"	7.537	7.184	-4.7	.028	.033	+17.9
120	"	6.248	5.978	-4.3	.025	.029	+16.0
171	"	6.131	5.848	-4.6	.031	.036	+16.1
206	"	8.258	7.890	-4.5	.033	.037	+12.1
252	"	8.452	8.101	-4.2	.028	.030	+ 7.1
78	Zinc	3.993	3.969	-0.6	.030	.030	+ 0.0
162	"	3.255	3.239	-0.5	.031	.032	+ 3.2

## 2.1 Silver-Oxide Electrode (Continued)

One noteworthy feature is the very angular nature and large overall size of the AgO at lower weights and density. The porosity or void area is also extensive for these electrodes. Both the structure and void area change considerably with increased weight and density. The angularity is not evident and the particles tend to form a more continuous mass, made up of smaller, more rounded agglomerated particles.

The angular particles ranged from a maximum in the range of 10 microns for one particle down to one micron or less. The smaller particles appeared to be more agglomerated, whereas the larger ones retained their identity and remained more separated from the mass. No two specimens were necessarily alike, but arrangement into a scale from very angular and open to agglomerated and dense would be possible.

In some cases it was difficult to obtain a clean, even break on the transverse sections, so it is possible that a few of the pictures could have been misleading.

The sterilized samples were very brittle and susceptible to crumbling. Because of the difficulty in getting a good sample, only surface shots were made.

The structures of all the samples appeared to become much more similar after sterilization. An overall agglomeration occurred with less apparent void space. There were no longer any of the individual angular particles that were present initially. All the particles appeared to be made up of a large number of small particles of about micron size.

The particles appear to result from some growth mechanism outward from the starting particle. All the electrodes after heating approached the structure that the denser, heavier

## 2.1 Silver-Oxide Electrode (Continued)

plates possessed before heating - namely, the agglomerated small particle-type structure. There was also a needle type growth in a few areas on some of the electrodes.

In general, there was much less uniformity over the entire surface area of a sterilized electrode than in the initial unsterilized plates, even though all the samples approached the same type. In other words, the majority of the electrodes will have similar areas, but the color, phases, and structure are more prone to vary within any one given electrode.

X-Rays were made primarily on one set of electrodes with common weights but varying densities. Patterns were made on the whole surface as well as of powders made by grinding up pieces taken from the electrodes.

Initially, the only phase present was AgO. After sterilization at 135°C for 128 hours, the samples appeared to be of a uniform dark to black color. Upon cooling a more mottled look appeared. The colors ranged from a light tan to intermediate shades of grey-brown to almost black. In examining surface X-Rays of sterilized plates, the samples were different in many respects. The powdered samples of these materials were very similar. This would indicate that either only the surface has any variations, or that the method of preparing the powdered specimens causes preferred phases to be collected. For example, a brittle phase (oxide, carbonate) would remain fine grained and powdery, while a ductile phase (silver) would agglomerate and flatten out being less likely to remain on the glass slide used to hold the powder for X-Ray.

The surface samples appear to be predominantly Ag and Ag<sub>2</sub>O, with possibly a small amount of AgCO<sub>3</sub>. When powdered, a considerable amount of AgCO<sub>3</sub> was found to be present. This may

## 2.1 Silver-Oxide Electrode (Continued)

not be representative or directly proportional to the amount in the plate, but it does show that this phase is present in all three. Evidently the carbonate was introduced during the sterilization of the plates.

The results of the B.E.T. tests conducted by American Instruments are not complete as yet. These involve measurements of the surface area of the electrodes. Effects of 128 hours of sterilization at 135°C on the surface area should be seen by these tests. Preliminary information indicates that the area is affected but the extent is not known. The data shall be presented when testing is completed.

## 2.2 Zinc Electrode

Coincidental with the studies made on the silver-oxide electrode, determinations of the effects of heat sterilization on the crystalline structure, porosity and surface area of the zinc electrode were made. Phase study determinations as well as microscope scanning shots (Appendix II) were made of several plates. There did not appear to be an appreciable oxidation of the zinc electrodes resulting from heating the plates at 135°C for 128 hours. The X-Rays taken before and after are almost identical, with only a Zn phase appearing. There was no evidence of any extensive amount of a ZnO phase. The weight changes were minor. However, the trend appeared to be inverse to that experienced before. All previous tests resulted in a weight increase and capacity loss. Since the two factors occurred coincidentally, the gain in weight was suspected as being oxygen. These data show essentially no significant weight changes during sterilization. Since the explanation for the lack of expected weight increase is not known, the tests are being repeated.

The tests performed at American Instruments indicate very little change, if any, in the surface area of the zinc plate after sterilization. The results of a two plate study are shown in



## 2.2 Zinc Electrode (Continued)

Table II. The variances between the unsterilized and sterilized readings are within the error of the technique.

## 2.3 Separator

Values for the resistance of several open type separators were determined during the past quarter. The separators were placed in the fixture shown in Figure II for measurement. The measurements were made with a 1000 Hz A.C. voltage and a fixed current of 0.5 ampere. Voltage readings were taken of the voltage drop across the electrolyte with no separator. The separator was then positioned in the fixture and voltage readings were taken again. Both measurements were recorded with a current of 0.5 amp.

The material used represented sterilized and unsterilized conditions. All of the materials previously tested were not readily available. However, the samples examined provide a representation of the various types of open separators. Two layers of the separator material were used in order to obtain a voltage differential sufficient to determine accurate values for the resistance. Since the materials used were essentially open separators, the value of resistance with respect to the number of layers should be relatively linear.

The results of the study are depicted in Table III. The values of resistance for unsterilized material ranged from 0.002 ohm to 0.029 ohm. Sterilized separator resistances had a spread of 0.002 ohm to 0.029 ohm. Frequently, the resistance calculated at 24 hours was higher for sterilized materials. Apparently, the 135°C sterilization made the separator more stable resulting in a relatively constant resistance.

## 2.4 Cell Case and Sealing

Various mechanical tests were conducted with polysulfone material. These included tensile and shear tests (lap joints) on fabricated components. Burst tests were conducted on molded cell cases. The specimens were stressed in unsterilized and sterilized conditions.

TABLE II  
EFFECTS OF 135°C STERILIZATION  
ON THE  
SURFACE AREA OF ZINC PLATES

Plate No.	Condition	B.E.T. Measurement (Square Meters/Gram)
43	Unsterilized	6.1
	Sterilized	5.8
312	Unsterilized	3.6
	Sterilized	4.8

FIGURE I

Fixture for Separator Resistance Measurement




TABLE III  
EFFECTS OF HEAT STERILIZATION  
ON THE  
RESISTANCE OF SEPARATOR MATERIAL

Sample No.	Type	Supplier	E*	Layers Tested	Resistance/Layer (Ohms)			Status
					0.5 Min.	5 Min.	24 Hrs.	
1	Asbestos 7410 40% Glass	Raybestos	.13	2	0.0235	0.0235	0.0039	Unsterilized
2			.15	2	0.037	0.029	0.029	Sterilized
3	Asbestos 7410/5 40% Glass	Raybestos	.03	2	0.0058	0.0058	0.002	Unsterilized
4			.03	2	0.0058	0.0058	0.0039	Sterilized
5	Asbestos 7401/5 5% Binder	Raybestos	.03	2	0.0058	0.0058	0.002	Unsterilized
6			.02	2	0.0058	0.0039	0.0039	Sterilized
7	Asbestos 7401 5% Binder	Raybestos	.02	2	0.0039	0.0039	0.002	Unsterilized
8			.01	2	0.002	0.002	0.002	Sterilized
9	Nylon/B 2504K	Pellon Corp.	.03	2	0.0058	0.0058	0.0039	Unsterilized
10			.02	2	0.0058	0.0039	0.0039	Sterilized
11	Nylon/B 2505	Pellon Corp.	.04	2	0.0098	0.0078	0.0058	Unsterilized
12			.03	2	0.0058	0.0058	0.0058	Sterilized
13	Nylon/B 2505K	Pellon Corp.	.04	2	0.0078	0.0078	0.0058	Unsterilized
14			.05	2	0.0118	0.0098	0.0098	Sterilized
15	Nylon/B 2505ML	Pellon Corp.	.04	2	0.0078	0.0078	0.0039	Unsterilized
16			.08	2	0.0156	0.0078	0.0078	Sterilized
17	Nylon/B 2506K	Pellon Corp.	.08	2	0.0156	0.0156	0.0118	Unsterilized
18			.07	2	0.0137	0.0137	0.0137	Sterilized
19	Nylon/B 2506M	Pellon Corp.	.04	2	0.037	0.0078	0.0058	Unsterilized
20			.11	2	0.035	0.0215	0.0196	Sterilized
21	Nylon/PP SM124.3	Kendall Mills.	.05	2	0.0118	0.0098	0.0098	Sterilized
22	Polypropylene EM476	Kendall Mills.	.06	2	0.0137	0.0118	0.0098	Unsterilized
23	Polypropylene 2530	Pellon Corp.	.08	2	0.0196	0.0196	0.0137	Unsterilized
24	Rayon R75D	Chicopee Mills	.04	2	0.0078	0.0078	0.0058	Unsterilized
25			.04	2	0.0098	0.0078	0.0078	Sterilized
26	Cotton 2409	Kendall Mills.	.03	2	0.0058	0.0058	0.0039	Unsterilized
27			.06	2	0.0118	0.0058	0.0058	Sterilized
28	Hemp Filpaco 4366T	Dexter	.02	2	0.0039	0.0039	0.002	Unsterilized
29			.01	2	0.002	0.002	0.002	Sterilized

\*This is the differential voltage between readings taken without separator and with separator

#### 2.4 Cell Case and Sealing (Continued)

Tensile and shear specimens were prepared using methylene chloride as the bonding agent. In the direct tensile samples the material was tapered to provide a joint approximately 0.5 inch in width. The material thickness was 0.125 inch. The shear specimens were made with an overlap of approximately 0.6 inch. Each sample was 1.0 inch in width. The pieces were broken using conventional test equipment and a steady cross-head movement. The parts were positioned in the jaws according to the type information desired. The manner in which the shear tests were held introduced some bending in the part. These samples all broke in an area adjacent to the lap joint. The load at the time of fracture ranged between 320 to 550 pounds. A rough calculation assuming strictly tensile loading indicates a breaking strength of 2500 to 4300 psi. The sterilized specimens were in the mid-range of the data as depicted in Table IV. The samples tested in tension broke within a range of 100 to 300 pounds. This represents stresses of 1660 to 5330 psi. The data from the sterilized parts were in the upper half of the range. Apparently, the joints were not made with sufficient pressure since the strengths of the tensile specimens are low.

A more definitive test of the polysulfone material was made using molded cell cases. Four cases were ruptured with nitrogen. Two of the four were sterilized prior to rupture. Each case had been sealed with methylene chloride and subjected to 85°C vacuum for 72 hours prior to testing. While the parts were examined visually for any crazing, a steady pressure increase was used to break the case. In each case the part failed without any crazing being seen. The major area exposed to pressure was 1.37 inches wide by 2.828 inches high with a wall thickness of 0.068 inch. The cases which had been sterilized failed at 85 and 90 psig while the unsterilized broke

TABLE IV  
MECHANICAL STRENGTHS OF STERILIZED AND UNSTERILIZED  
POLYSULFONE JOINTS

Sample	Area of Fracture (Sq. In.)	Load at Failure (psi)	Stress (psi)	Sterilized	Remarks
1	.128	430	3360	Yes	Lap joint, failed adjacent to joint
2	.127	460	3630	No	Lap joint, failed adjacent to joint
3	.128	320	2500	Yes	Lap joint, failed adjacent to joint
4	.128	550	4300	No	Lap joint, failed adjacent to joint.
5	.0631	200	3170	Yes	Butt joint, failed at joint
6	.0562	300	5330	Yes	Butt joint, failed at joint
7	.0602	100	1660	No	Butt joint, failed at joint
8	.0610	200	3280	No	Butt joint, failed at joint
9	2.828 x 1.375	85	*	Yes	Cell case, failed at wall described
10	2.828 x 1.375	90	*	Yes	Cell case, failed at wall described
11	2.828 x 1.375	175	*	No	Cell case, failed at wall described
12	2.828 x 1.375	140	*	No	Cell case, failed at wall described

\* - Value Not Determined

#### 2.4 Cell Case and Sealing (Continued)

at 140 and 175 psig. Apparently, sterilization effected a loss in strength of approximately 40%. Each part failed in the manner expected.

#### 2.5 Pyrotechnics

As a result of a continuation of studies involving pyrotechnics, an initiator developed by Networks Electronics utilizing pyro-fuse as the bridgewire has shown evidence of being capable of heat sterilization. Five of these units were subjected to 135°C heat sterilization for 128 hours. After sterilization a no-fire current of 0.5 ampere was imposed on each igniter for 16 seconds followed by a sure-fire current of 2.0 amperes. No malfunctions occurred.

#### 2.6 Cell Design

Entering into Phase II of the program, various cell designs were prepared for testing. The capacity requirements are either a 1200 watt rate for 10 minutes or a 500 watt rate for 24 minutes. The terminal voltage of the battery should be in the range of 26 to 30 volts when under the referenced loads. One design was selected for testing to verify the capacity.

Five cells were made using five negative and four positive plates separated by asbestos (.010 inch thickness) and 4366T hemp fiber (.0045 inch thickness). The cells were encased in fabricated polysulfone cases and sterilized 128 hours at 135°C while dry. Activated with 1.30 specific gravity potassium hydroxide, the cells were discharged according to the following schedule.

<u>Cell No.</u>	<u>Wet Stand</u> (Hours)	<u>Discharge Rate</u> (Amperes)
1	0.5	19.2
2	0.5	46.2
3	72	46.2 - 5 Min. & 19.2
4	144	46.2 - 5 Min. & 19.2
5	288	46.2 - 5 Min. & 19.2

## 2.6 Cell Design (Continued)

In each case the cells were marginal in capacity. Examination of the data (Figures II through V) and the expended cells revealed a shortage of negative material in the cell. The fifth cell failed to respond when the discharge load was applied. Evidently silver penetration of the separator had decreased the resistance of the separator sufficiently to permit the cell to discharge during the wet stand.

Two cells were made and discharged with each of the three inside negative plates replaced by two plates. Each of the two plates were the same as the one replaced. The cells were activated and allowed to stand for 0.5 hour prior to discharge. One cell was discharged at 46.2 amps while the other was discharged at 19.2 amps. Curves depicting the voltage-time profiles may be seen in Figures VI and VII. As can be seen by the curves, the marginal capacity condition has been eliminated by the increase in negative material.

## 3.0 CONCLUSIONS

As a result of studies made during the past quarter, the following conclusions may be made. Prior to sterilization, the crystalline structure of the silver-oxide electrode is irregular. On a plate-to-plate comparison there is no similarity. After sterilization the electrodes become more uniform when compared on a plate-to-plate basis. However, the surface areas of individual plates were found to be less uniform after sterilization.

Prior to heat sterilization, the only phase present on the silver-oxide plates was determined to be  $\text{Ag}_2\text{O}$ . Subsequent to sterilization the predominant phases found by X-Ray were  $\text{Ag}$  and  $\text{Ag}_2\text{O}$ , with a small amount of  $\text{AgCO}_3$ .

Microscope scanning of zinc electrodes indicates that no significant changes occur in the physical structure as a result of heat sterilization. This was verified by B.E.T. surface area measurements.



FIGURE 11  
 CELL NO. 1  
 Discharge Characteristics  
 After  
 Near Sterilization  
 Separation: 0.10 asbestos and  
 4300T Temp  
 30 Minute Wet Stand




FIGURE III  
 CELL NO. 2  
 Discharge Characteristics  
 After  
 Meat Sterilization  
 Separation: 0.6 Asbestos and  
 7.366T Hemp  
 30 Minute Wet Stand




FIGURE IV  
CMT: NO. 3  
Discharge Characteristics  
After  
Heat Sterilization  
Separation: 610 Asbestos and  
43661 Hemp  
1/2 Hour Net Stand




FIGURE IV  
 CELL NO. 4  
 Discharge Characteristics  
 After  
 Heat Sterilization  
 Separator: 0.00 Asbestos and  
 43601 Namp  
 100 Hour Wat. Stand






FIGURE VI  
CELL NO. 6  
Discharge Characteristics  
After  
Heat Sterilization  
Separation: 310 Asbestos and  
43601 Ramp  
30 Minute Wet Stand





FIGURE VII  
CMI NO. 7  
Discharge Characteristics  
After  
Heat Sterilization  
Separation: 010 Ashes and  
43651 Hemp  
10 Minute Wet Stand



### 3.0 CONCLUSIONS (Continued)

The resistances of the unsterilized separator materials measured as a function of time immersed in potassium hydroxide (1.30 specific gravity) were almost always higher initially than at the 24 hour point. After sterilization the resistance tends to stabilize at the lower levels.

Burst tests conducted on molded polysulfone cell cases indicate a 40% loss in strength due to sterilization.

### 4.0 RECOMMENDATIONS

Work will continue under Phase II.

### 5.0 NEW TECHNOLOGY

No new technology was developed during the fourth quarter of the contract.

APPENDIX I  
MICROSCOPIC STUDY OF SILVER-OXIDE ELECTRODES



300 Magnification

Silver Oxide Plate No. 35  
As Received  
Flat Surface

1000 Magnification



300 Magnification

Silver Oxide Plate No. 35

As Received

Transverse View

1000 Magnification





300 Magnification

Silver Oxide Plate No. 35

Sterilized

Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 67

As Received

Transverse View

1000 Magnification









300 Magnification

Silver Oxide Plate No. 67  
Sterilized  
Flat Surface

1000 Magnification







300 Magnification


Silver Oxide Plate No. 83

As Received

Flat Surface

1000 Magnification







300 Magnification


Silver Oxide Plate No. 83

As Received

Transverse View

1000 Magnification







300 Magnification



Silver Oxide Plate No. 83

Sterilized

Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 95

As Received

Flat Surface

1000 Magnification








300 Magnification

Silver Oxide Plate No. 95  
As Received  
Transverse View

1000 Magnification








300 Magnification

Silver Oxide Plate No. 95  
Sterilized  
Flat Surface

1000 Magnification








1000 Magnification  
Silver Oxide Plate No. 95  
Sterilized  
Flat Surface







300 Magnification


Silver Oxide Plate No. 106

As Received

Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 106

As Received

Transverse View

1000 Magnification







300 Magnification


Silver Oxide Plate No. 106

Sterilized

Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 120

As Received

Flat Surface

1000 Magnification








1000 Magnification  
Silver Oxide Plate No. 120  
As Received  
Flat Surface







300 Magnification

Silver Oxide Plate No. 120

As Received

Transverse View

1000 Magnification





300 Magnification


Silver Oxide Plate No. 120

Sterilized

Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 171

As Received

Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 171

As Received

Transverse View

1000 Magnification









300 Magnification

Silver Oxide Plate No. 171

Sterilized  
Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 206

As Received

Flat Surface

1000 Magnification









300 Magnification

Silver Oxide Plate No. 206  
As Received  
Transverse View

1000 Magnification







300 Magnification


Silver Oxide Plate No. 206

Sterilized

Flat Surface

1000 Magnification







300 Magnification


Silver Oxide Plate No. 252

As Received

Flat Surface

1000 Magnification







300 Magnification



Silver Oxide Plate No. 252

As Received

Transverse View

1000 Magnification







300 Magnification



Silver Oxide Plate No. 252

Sterilized

Flat Surface

1000 Magnification









1000 Magnification  
Silver Oxide Plate No. 252  
Sterilized  
Flat Surface







APPENDIX II

MICROSCOPIC STUDY OF ZINC ELECTRODES







300 Magnification



Zinc Plate No. 51

Sterilized

Flat Surface

1000 Magnification







300 Magnification



Zinc Plate No. 78

As Received

Flat Surface

1000 Magnification









300 Magnification

Zinc Plate No. 78  
As Received  
Transverse View

1000 Magnification









300 Magnification

Zinc Plate No. 78  
Sterilized  
Flat Surface

1000 Magnification







300 Magnification



Zinc Plate No. 162

As Received

Flat Surface

1000 Magnification







300 Magnification



Zinc Plate No. 162

As Received

Transverse View

1000 Magnification







300 Magnification

Zinc Plate No. 162

Sterilized

Flat Surface

1000 Magnification



